

# Kassini Assembly Instructions

## Fittings Included



Workstation



Screws x 4

## Assembly Instructions



- 1 Interlock the Modesty Panel ends into the legs and tighten
- 2 Replace interlocking infill panel on legs
- 3 Insert 40mm Screws through upper leg casts and into pilot holes in table top

## Tools Required



Pozi Screwdriver